





The box contains:

- Wooden digital clock
- USB power cord
- user 's manual

Product Description:

Power Supply 1.5 M USB-C Cable
(5V /1A USB adapter excluded)

Material style MDF and PVC

Use Home decoration

Hourly format

- Press “down” to switch the 12 / 24-hour system
- 12 hour format display: display “PM” light from noon to midnight

Hour

- Long press the “set” key to enter the setting mode.
- When the hour number flashes, use the “up” and “down” keys to adjust the hour

Minute

- Press the “set” key again to enter the setting mode.
- When the minute number flashes, use the “up” and “down” keys to adjust the minute.
- Hourly format (12 / 24 hours)
- The setting interface will exit automatically if there is no operation in 15 seconds.

Matters needing attention:

- For power only use a 5V / 1A USB adapter for this product.

⚠ Danger warning: Be sure to use an adapter within the standard voltage range.

- Keep the clock and power cord out of the reach of infants or children. If you swallow any small part, Seek medical attention immediately.
- If you can't maintain the normal running inside the movement in case of power failure, please check whether the battery (CR2032) is installed or may be out of power. Please replace the battery in time.

Warning

- Do not use the product near flammable objects and heat sources.
- Do not use this product in high temperature or high humidity environments (such as bathrooms), this product has no waterproof function.
- Do not disassemble or modify the product.
- Handle the product with care. The product might break when its dropped