

INSTRUCTIONS**ACTIVATING THE CLOCK**

To replace the battery insert 1 xAA(1.5V)into the battery compartments, taking care to observe the correct polarity.

TIME SETTING

To set the clock to the desired time, rotate the time set knob' until the correct time is reached.

